

PS Eliminator Supplementary Manual



MV Agusta F4 1000 2004-2012 (PSE-01)

Secure the bike on a stand.



Remove the seat.

Remove the fuel tank.



Locate the stock PAIR (clean air) valve
and unplug the connector.

Remove the PAIR (clean air) valve.

(Blue, 2-pole connector)

