

PS Eliminator Supplementary Manual



MV Agusta F4 Biposto 1078 2008-2009 (PSE-01)

Secure the bike on a stand.



Remove the seat and the side fairings.

Remove the fuel tank.



Locate the stock PAIR (clean air) valve and unplug the connector.

Remove the PAIR (clean air) valve.

(Blue, 2-pole connector)



PS Eliminator Supplementary Manual



MV Agusta F4 Biposto 1078 2008-2009 (PSE-01)

Plug the PSE module into the wiring harness connector.

Secure the unit properly.

