

PS Eliminator Supplementary Manual



Suzuki DL1000 V-Strom 2017-2020 (PSE-01)

Secure the bike on a stand.



Remove the seat.


Remove the side fairings.

Remove the fuel tank and the airbox.



Locate the stock PAIR (clean air) valve
under the airbox on the right side and
unplug the connector.

(Black, 2-pole connector.)



PS Eliminator Supplementary Manual



Suzuki DL1000 V-Strom 2017-2020 (PSE-01)

Remove the PAIR (clean air) valve.

Plug the PSE module into the wiring harness connector.

Secure the unit properly.

