

PS Eliminator

Supplementary Manual



Suzuki GSF1250 Bandit ABS 2007-2016 (PSE-01)

Secure the bike on a stand.



Remove the seat and the side fairings.

Remove the fuel tank and the airbox.

Locate the stock PAIR (clean air) valve and unplug the connector.

Remove the PAIR (clean air) valve.

(Black, 2-pole connector)



Plug the PSE module into the wiring harness connector.

Secure the unit properly.

