

PS Eliminator Supplementary Manual

Suzuki GSX-R125 ABS 2022- (PSE-01)

Secure the bike on a stand.



Remove the seats.

Remove the side fairings.



Locate the stock PAIR (clean air) valve under the fuel tank and unplug the connector.



PS Eliminator Supplementary Manual



Suzuki GSX-R125 ABS 2022- (PSE-01)

Remove the PAIR (clean air) valve.

Plug the PSE module into the wiring harness connector.

Secure the unit properly.

