PS Eliminator

Supplementary Manual



Suzuki GSX-S1000F ABS TC 2015- (PSE-01)

Secure the bike on a stand.



Remove the seats.

Remove the side fairings.


Remove the plastic covers from the fuel tank.

Remove the fuel tank and the airbox.



Locate the stock PAIR (clean air) valve and unplug the connector.

(Green, 2-pole connector under the airbox.)



PS Eliminator

Supplementary Manual



Suzuki GSX-S1000F ABS TC 2015- (PSE-01)

Remove the PAIR (clean air) valve.

Plug the PSE module into the wiring harness connector.

Secure the unit properly.

