

# PS Eliminator Supplementary Manual

## Suzuki GSX250R ABS 2018-2021 (PSE-01)

Secure the bike on a stand.



Remove the seats and remove the fuel tank.



Locate the stock PAIR (clean air) valve and unplug the connector.



# PS Eliminator Supplementary Manual



## Suzuki GSX250R ABS 2018-2021 (PSE-01)

Remove the PAIR (clean air) valve.

Plug the PSE module into the wiring harness connector.

Secure the unit properly.

