

PS Eliminator Supplementary Manual




Suzuki SV650X 2018- (PSE-01)

Remove the side fairing.

Locate the stock PAIR (clean air) valve and unplug the connector.

(Black, 2-pole connector on the right side, below the fuel tank.)



Remove the PAIR (clean air) valve.

Plug the PSE module into the wiring harness connector.



Typical position for the PSE module.

Secure the unit properly.

