

PS Eliminator Supplementary Manual



Honda CBR1000RR 2004-2005 (PSE-02)

Secure the bike on a stand.




Remove the seats.

Remove the plastic covers from the fuel tank.

Lift up or remove the fuel tank and remove the airbox.



Locate the stock PAIR (clean air) valve and unplug the connector.



PS Eliminator Supplementary Manual



Honda CBR1000RR 2004-2005 (PSE-02)

Remove the PAIR (clean air) valve.

Plug the PSE module into the wiring harness connector.

Secure the unit properly.

