

QuickShifter easy Supplementary Manual



Yamaha YZF-R6 2003-2005 (iQSE-1 + QSH-F4B)

Remove the passenger seat.

Remove the main seat.



Lift up or remove the fuel tank.



Plug the QSH connectors in-line with the
fuel injector connectors.

(Gray, 2-pole connectors below the airbox)



QuickShifter easy Supplementary Manual



Yamaha YZF-R6 2003-2005 (iQSE-1 + QSH-F4B)

Connect the QSH Black wire terminal to the battery negative terminal.

(The picture on the right shows an alternative location, but we recommend using the battery negative terminal)



Mount the QSE sensor.

(Replace the bolt with the one supplied. Place the supplied washers at both sides of the sensor. Tighten the bolt in this position by about 6 Nm. If you do not have torque wrench, tighten the bolt until the shift arm is tight on the gearbox shaft.)



Typical position for the QuickShifter easy.

Secure the unit properly.

