
QuickShifter easy Supplementary Manual



Honda CBR1000RR 2006-2007 (iQSE-1 + QSH-P4B)

Remove the main seat.



Remove the black side covers from the fuel tank cover.

Remove the fuel tank cover.



Remove the fuel tank.



QuickShifter easy Supplementary Manual



Honda CBR1000RR 2006-2007 (iQSE-1 + QSH-P4B)

Remove the airbox.



Remove the air intake below the airbox.



Plug the QSH connectors in-line with the ignition coil connectors.

(Black, 2-pole connectors below the air intake)




QuickShifter easy Supplementary Manual



Honda CBR1000RR 2006-2007 (iQSE-1 + QSH-P4B)

Connect the QSH Black wire terminal to the chassis ground.



Mount the QSE sensor.

(Replace the bolt with the one supplied.

Place the conical washers at the two sides of the sensor like this: (0). Tighten the bolt in this position by about 6 Nm. If you do not have torque wrench, tighten the bolt until the shift arm is tight on the gearbox shaft.)



Typical position for the QuickShifter easy.

Secure the unit properly.

