

## Suzuki GSX-R1000 2007-2008 (iQSE-1 + QSX-P4B)

Remove the main seat.



Remove the black fuel tank covers.



Remove the fuel tank.



# QuickShifter easy Supplementary Manual



## Suzuki GSX-R1000 2007-2008 (iQSE-1 + QSX-P4B)

Remove the airbox.



Plug the QSX connectors in-line with the ignition coil connectors.

*(Black, 2-pole connectors below the airbox)*



Mount the QSX module to the inner side of the frame by the supplied Velcro strips, and secure the cables with cable ties.

*(Avoid direct contact with heat sources, like the cylinder head.)*





# QuickShifter easy Supplementary Manual



## Suzuki GSX-R1000 2007-2008 (iQSE-1 + QSX-P4B)

Connect the QSX Black wire terminal to the chassis ground.



Mount the QSE sensor.

*(Replace the bolt with the one supplied. Place the conical washers at the two sides of the sensor like this: (O). Tighten the bolt in this position by about 6 Nm. If you do not have torque wrench, tighten the bolt until the shift arm is tight on the gearbox shaft.)*



Typical position for the QuickShifter easy.

Secure the unit properly.

