

Honda CRF300L ABS 2021- (SH-V4 + SH-H08)

Secure the bike on a stand.



Remove the seat.


Remove the side fairings.

Remove the fuel tank.



Locate the vehicle speed sensor
connectors.

*(Blue, 3-pole connectors under the fuel
tank)*




SpeedoHealer Supplementary Manual



Honda CRF300L ABS 2021- (SH-V4 + SH-H08)

Plug the SpeedoHealer connectors in-line with the vehicle speed sensor connectors.



Typical position for the remote button.



Typical position for the SpeedoHealer.

Secure the unit properly.

