

Kawasaki ZX-6R 1998-2004 (SH-V4 + SH-K01)

Secure the bike on a stand.

Remove the seats.

Remove or lift up the fuel tank.



Locate the vehicle speed sensor connectors.



Plug the SpeedoHealer connectors in-line with the vehicle speed sensor connectors.



SpeedoHealer

Supplementary Manual



Kawasaki ZX-6R 1998-2004 (SH-V4 + SH-K01)

Typical position for the SpeedoHealer.

Secure the unit properly.

