

# SpeedoHealer

## Supplementary Manual



### Kawasaki ZX-6R 2007-2008 (SH-V4 + SH-K01)

Secure the bike on a stand.



Remove the seat.

Remove or lift up the fuel tank.



Locate the vehicle speed sensor connectors.

Plug the SpeedoHealer connectors in-line with the vehicle speed sensor connectors.



# SpeedoHealer

## Supplementary Manual



### Kawasaki ZX-6R 2007-2008 (SH-V4 + SH-K01)

Typical position for the SpeedoHealer.

Secure the unit properly.

