


Kawasaki ZX-10R 2006-2007 (SHv4 + SH-K06)


Remove the frame covers below main seat .



Remove the main seat.



Lift up or remove the fuel tank.



SpeedoHealer

Supplementary Manual



Kawasaki ZX-10R 2006-2007 (SHv4 + SH-K06)

Plug SpeedoHealer connectors in-line with the vehicle speed sensor (vss) connectors.

(black, 3-pole connectors at left side behind water hose)



Typical position for SpeedoHealer.

