

Suzuki B-King 2008-2012 (SH-V4 + SH-S01)

Secure the bike on a stand.



Remove the seats.

Remove the covers from the fuel tank.


Remove the fuel tank.



Locate the vehicle speed sensor connectors.

Plug the SpeedoHealer connectors in-line with the vehicle speed sensor connectors.

(Black, 3-pole connectors under the fuel tank)



Suzuki B-King 2008-2012 (SH-V4 + SH-S01)

Typical position for the remote button.



Typical position for the SpeedoHealer.

Secure the unit properly.

