

Triumph Speed Triple 2005-2010 (SH-V4 + SH-T01)

Remove the seat and remove the fuel tank.



Remove the airbox.



Plug the SpeedoHealer connectors in-line with the vehicle speed sensor connectors.

(Black, 3-pole triangular connectors at the left side below the airbox)



Triumph Speed Triple 2005-2010 (SH-V4 + SH-T01)

Typical position for the SpeedoHealer.

Secure the unit properly.

