

SpeedoHealer

Supplementary Manual



Yamaha YZF-R6 2003-2004 (SH-V4 + SH-Y01)

Secure the bike on a stand.

Remove the seats.

Lift up or remove the fuel tank.



Locate the vehicle speed sensor connectors.

Plug the SpeedoHealer connectors in-line with the vehicle speed sensor connectors.

(White, 3-pole connectors under the fuel tank)



Typical position for the SpeedoHealer.

Secure the unit properly.

