Shift Light pro

Supplementary Manual



KTM SMR 450 2004-2007 (SLP-U01)

Secure the bike on a stand.



Remove the left and right side plastic covers.



Remove the the fuel tank.




Shift Light proSupplementary Manual



KTM SMR 450 2004-2007 (SLP-U01)

Connect the SLP Black/Green wire to the Red wire of the crankshaft position sensor connector.

(Blue, 2-pole connector below the fuel tank.)




Connect the SLP Black wire to the ignition coil Brown wire (ground terminal).

Also connect the ignition coil ground terminal to the battery negative terminal.



Connect the SLP Red wire to the battery positive terminal via an on/off switch.



Shift Light proSupplementary Manual



KTM SMR 450 2004-2007 (SLP-U01)

Typical position for the Shift Light pro.

Secure the unit properly.

(Shown with the optional Gipro Mount, part no.: GIPRO-M-BK)

