

STV Eliminator Supplementary Manual

Suzuki GSX-R600 2004-2005 (STVE-12)

Secure the bike on a stand.



Remove the seats.


Lift up or remove the fuel tank.

Remove the airbox.



Locate the throttle body assembly under the airbox tank.

Find the two connectors of the actuator motor and the STPS (secondary throttle position sensor) on the throttle body assembly.



STV Eliminator Supplementary Manual



Suzuki GSX-R600 2004-2005 (STVE-12)

Remove the butterfly valve flaps/throttle plates.

Plug the STVE module into the 4-pole Black wiring harness connector.

Plug the STVE module into the 3-pole Black wiring harness connector.

Secure the unit properly.

