

PS Eliminator Supplementary Manual



Triumph Thruxton 1200 ABS TC RS 2016- (PSE-01)

Secure the bike on a stand.




Remove the seat.

Remove the fuel tank.



Locate the stock PAIR (clean air) valve
and unplug the connector.



PS Eliminator Supplementary Manual



Triumph Thruxton 1200 ABS TC RS 2016- (PSE-01)

Remove the PAIR (clean air) valve.

Plug the PSE module into the wiring harness connector.

Secure the unit properly.

